



Lynx600-AC ADAPTADOR USB | INALÁMBRICO AC DE DOBLE BANDA
Modelo: AULUB605U1

Guía de instalación rápida

1. Introducción

1. Inserte primero el adaptador de red USB en el puerto correspondiente de su computador.



Contenido del empaque

Si faltara cualquiera de los artículos mencionados, estúviera dado o si no coincide con la lista, contáctese de inmediato con el proveedor adonde adquirió la unidad para su reemplazo.

- Adaptador USB AC, de doble banda
Guía de instalación rápida
CD ROM (con copia digital de la guía de instalación rápida y herramienta de configuración del controlador)

2. Wizard (Asistente para detectar nuevo dispositivo)

Si aparece el cuadro de diálogo Found New Hardware Wizard (Asistente para detectar nuevo dispositivo), presione Setup.exe con el cursor sobre el CD del software para instalar manualmente la aplicación.

2. Aparece el sistema detecta el adaptador; éste comienza a descargar el Asistente, tal como se indica a continuación.



Configuración inicial

1. Introduzca el CD de ejecución en la unidad lectora de CD-ROM de la computadora. Seleccione Run (Ejecutar) para continuar.

3. Cuando se termina de cargar la herramienta de configuración del controlador, haga clic en Next para continuar.



2. Después de que se termina de cargar el programa, de cargar el programa.

4. La barra de estado nrá exhibiendo el avance a medida que se realiza el proceso de instalación en la computadora.



5. Es necesario esperar unos minutos para que se termine de cargar el programa.



6. Si la instalación del controlador concluye en forma satisfactoria, es posible que se le pida al usuario que reinicie el sistema de inmediato o más tarde. Lo anterior depende del sistema operativo.



Configuración de una conexión a red inalámbrica en Windows 7

1. Haga clic sobre el icono de conexión inalámbrica ubicado en la barra de estado.

2. Escoge la red inalámbrica a la cual desea conectarse.




3. Si la red a la cual se conecta está protegida, el sistema le pedirá que ingrese una contraseña. Haga clic en Aceptar cuando haya ingresado la clave de seguridad correcta.




4. La ventana a continuación despliega el mensaje Conectado una vez establecido el enlace a la red.



5. A partir de entonces, el usuario podrá comenzar a disfrutar del acceso inalámbrico para conectarse a Internet.



6. Es posible desconectar, visualizar el estado funcional o modificar las propiedades de la red inalámbrica con tan sólo hacer clic derecho sobre el icono que representa el dispositivo de red.



7. Declaración de la Comisión Federal de Telecomunicaciones
Tras haber sido sometido a todas las pruebas pertinentes, se ha comprobado que este equipo cumple con los límites establecidos para dispositivos digitales Clase B, conforme a la Sección 15 del Reglamento de la Comisión Federal de Comunicaciones (FCC). Tales límites definen los niveles máximos permitidos a las interferencias nocivas de la energía radiada en instalaciones residenciales. Puesto que el actual equipo genera, utiliza y puede radiar energía radiada en instalaciones residenciales, el usuario debe ser informado de las siguientes medidas con el objeto de corregir la situación.

Este equipo cumple con los límites de exposición a la radiación radioeléctrica establecida por la FCC en un ambiente no controlado y cumple además con la Sección 15 del Reglamento de la FCC para RF. Este equipo debe ser instalado y operado conforme a las instrucciones suministradas, mientras que la antena o antenas utilizadas para este transmisor deben ser montadas de tal forma de mantener una separación no inferior a 20cm de las personas, las cuales tampoco pueden ser colocadas ni operadas en conjunto con ninguna otra antena o transmisor. El consumidor final y personal técnico deben recibir las instrucciones para instalar la antena antes de considerar la eliminación de la declaración relativa a la no colocación de instrucciones para instalar la antena antes de considerar la eliminación de la declaración relativa a la no colocación de componentes respectiva.

8. Declaración relativa a la exposición radioeléctrica
Este equipo cumple con los límites de exposición a la radiación radioeléctrica establecida por la FCC en un ambiente no controlado y cumple además con la Sección 15 del Reglamento de la FCC para RF. Este equipo debe ser instalado y operado conforme a las instrucciones suministradas, mientras que la antena o antenas utilizadas para este transmisor deben ser montadas de tal forma de mantener una separación no inferior a 20cm de las personas, las cuales tampoco pueden ser colocadas ni operadas en conjunto con ninguna otra antena o transmisor. El consumidor final y personal técnico deben recibir las instrucciones para instalar la antena antes de considerar la eliminación de la declaración relativa a la no colocación de instrucciones para instalar la antena antes de considerar la eliminación de la declaración relativa a la no colocación de componentes respectiva.

9. Advertencia
Cualquier modificación sin la expresa aprobación de la parte responsable puede anular la garantía del usuario para operar el equipo.

10. Advertencia
Cualquier modificación sin la expresa aprobación de la parte responsable puede anular la garantía del usuario para operar el equipo.

11. Advertencia
Cualquier modificación sin la expresa aprobación de la parte responsable puede anular la garantía del usuario para operar el equipo.

12. Advertencia
Cualquier modificación sin la expresa aprobación de la parte responsable puede anular la garantía del usuario para operar el equipo.



Quick installation guide

1. Introduction

Thank you for purchasing the new Wireless AC dual-band USB adapter from Next Solutions™. In order to take advantage of this advanced wireless technology, we recommend including our Dual Band AC wireless router in your network.

Package content

If any of the following items are mismatched, missing or damaged, please contact the merchant from whom you purchased the unit for immediate replacement.

- One dual band AC USB adapter
One quick installation guide
One CD ROM (with a digital copy of the quick installation guide, and driver configuration tool)

Installing the USB network adapter

1. Insert the wireless USB adapter into an available USB port on your computer.




2. If the Found New Hardware Wizard system dialogue appears, select Cancel and use the included Setup Wizard software CD for fast installation



Initial setup

1. Insert the supplied software CD into the CD drive of your computer. Click on the Run button to continue. (If the automatic run fails, double click Setup.exe in the software CD to manually install the software).

2. As soon as the system detects the adapter, the Wizard will begin downloading, as shown in the illustration.



3. Once the driver configuration tool is complete, click Next to continue.



4. The status bar will show the progress as the driver installation on your computer is underway.



5. Please allow a few minutes for the installation process to conclude.



6. If the driver has been successfully installed, the user may be prompted to reboot the system either immediately or at a later time. This will depend on your operating system.




7. Click Finish to complete the installation.

Wireless network configuration in Windows 7

1. Click the wireless connection icon in the lower right corner of the computer desktop to view the available network.

2. Select the wireless network you wish to connect to.



4. Once the connection has been established successfully, the Connected message will be displayed.



3. If the wireless network you are connecting to is protected, you will be prompted to enter a password. Click OK once you have typed the correct security key.

2. Select the wireless network you wish to connect to.




7. Click Finish to complete the installation.

Wireless network configuration in Windows 7

1. Click the wireless connection icon in the lower right corner of the computer desktop to view the available network.

2. Select the wireless network you wish to connect to.



4. Once the connection has been established successfully, the Connected message will be displayed.



3. If the wireless network you are connecting to is protected, you will be prompted to enter a password. Click OK once you have typed the correct security key.

2. Select the wireless network you wish to connect to.




7. Click Finish to complete the installation.

Wireless network configuration in Windows 7

1. Click the wireless connection icon in the lower right corner of the computer desktop to view the available network.

2. Select the wireless network you wish to connect to.



4. Once the connection has been established successfully, the Connected message will be displayed.



3. If the wireless network you are connecting to is protected, you will be prompted to enter a password. Click OK once you have typed the correct security key.

2. Select the wireless network you wish to connect to.



7. Click Finish to complete the installation.

Wireless network configuration in Windows 7

1. Click the wireless connection icon in the lower right corner of the computer desktop to view the available network.

2. Select the wireless network you wish to connect to.



4. Once the connection has been established successfully, the Connected message will be displayed.



3. If the wireless network you are connecting to is protected, you will be prompted to enter a password. Click OK once you have typed the correct security key.

2. Select the wireless network you wish to connect to.



7. Click Finish to complete the installation.

Wireless network configuration in Windows 7

1. Click the wireless connection icon in the lower right corner of the computer desktop to view the available network.

2. Select the wireless network you wish to connect to.



4. Once the connection has been established successfully, the Connected message will be displayed.



3. If the wireless network you are connecting to is protected, you will be prompted to enter a password. Click OK once you have typed the correct security key.

2. Select the wireless network you wish to connect to.



7. Click Finish to complete the installation.

Wireless network configuration in Windows 7

1. Click the wireless connection icon in the lower right corner of the computer desktop to view the available network.

2. Select the wireless network you wish to connect to.



4. Once the connection has been established successfully, the Connected message will be displayed.



3. If the wireless network you are connecting to is protected, you will be prompted to enter a password. Click OK once you have typed the correct security key.

2. Select the wireless network you wish to connect to.




7. Click Finish to complete the installation.

Wireless network configuration in Windows 7

1. Click the wireless connection icon in the lower right corner of the computer desktop to view the available network.

2. Select the wireless network you wish to connect to.



4. Once the connection has been established successfully, the Connected message will be displayed.



3. If the wireless network you are connecting to is protected, you will be prompted to enter a password. Click OK once you have typed the correct security key.

2. Select the wireless network you wish to connect to.



7. Click Finish to complete the installation.

Wireless network configuration in Windows 7

1. Click the wireless connection icon in the lower right corner of the computer desktop to view the available network.

2. Select the wireless network you wish to connect to.



4. Once the connection has been established successfully, the Connected message will be displayed.



3. If the wireless network you are connecting to is protected, you will be prompted to enter a password. Click OK once you have typed the correct security key.

2. Select the wireless network you wish to connect to.




7. Click Finish to complete the installation.

Wireless network configuration in Windows 7

1. Click the wireless connection icon in the lower right corner of the computer desktop to view the available network.

2. Select the wireless network you wish to connect to.



4. Once the connection has been established successfully, the Connected message will be displayed.



3. If the wireless network you are connecting to is protected, you will be prompted to enter a password. Click OK once you have typed the correct security key.

2. Select the wireless network you wish to connect to.




7. Click Finish to complete the installation.

Wireless network configuration in Windows 7

1. Click the wireless connection icon in the lower right corner of the computer desktop to view the available network.

2. Select the wireless network you wish to connect to.



4. Once the connection has been established successfully, the Connected message will be displayed.



3. If the wireless network you are connecting to is protected, you will be prompted to enter a password. Click OK once you have typed the correct security key.

2. Select the wireless network you wish to connect to.




7. Click Finish to complete the installation.

Wireless network configuration in Windows 7

1. Click the wireless connection icon in the lower right corner of the computer desktop to view the available network.

2. Select the wireless network you wish to connect to.



4. Once the connection has been established successfully, the Connected message will be displayed.



3. If the wireless network you are connecting to is protected, you will be prompted to enter a password. Click OK once you have typed the correct security key.

2. Select the wireless network you wish to connect to.



7. Click Finish to complete the installation.

Wireless network configuration in Windows 7

1. Click the wireless connection icon in the lower right corner of the computer desktop to view the available network.

2. Select the wireless network you wish to connect to.



4. Once the connection has been established successfully, the Connected message will be displayed.



3. If the wireless network you are connecting to is protected, you will be prompted to enter a password. Click OK once you have typed the correct security key.

2. Select the wireless network you wish to connect to.




7. Click Finish to complete the installation.

Wireless network configuration in Windows 7

1. Click the wireless connection icon in the lower right corner of the computer desktop to view the available network.

2. Select the wireless network you wish to connect to.



4. Once the connection has been established successfully, the Connected message will be displayed.



3. If the wireless network you are connecting to is protected, you will be prompted to enter a password. Click OK once you have typed the correct security key.

2. Select the wireless network you wish to connect to.



7. Click Finish to complete the installation.

Wireless network configuration in Windows 7

1. Click the wireless connection icon in the lower right corner of the computer desktop to view the available network.

2. Select the wireless network you wish to connect to.



4. Once the connection has been established successfully, the Connected message will be displayed.



3. If the wireless network you are connecting to is protected, you will be prompted to enter a password. Click OK once you have typed the correct security key.

2. Select the wireless network you wish to connect to.



7. Click Finish to complete the installation.

Wireless network configuration in Windows 7

1. Click the wireless connection icon in the lower right corner of the computer desktop to view the available network.

2. Select the wireless network you wish to connect to.



4. Once the connection has been established successfully, the Connected message will be displayed.



3. If the wireless network you are connecting to is protected, you will be prompted to enter a password. Click OK once you have typed the correct security key.

2. Select the wireless network you wish to connect to.




7. Click Finish to complete the installation.

Wireless network configuration in Windows 7

1. Click the wireless connection icon in the lower right corner of the computer desktop to view the available network.

2. Select the wireless network you wish to connect to.



4. Once the connection has been established successfully, the Connected message will be displayed.

